



Operating the BEST 548 or Low Step Folding Fat Tire Electric Bike

1. Turn the key to “ON” position
2. Press the “ON” button in center of LCD display and hold till display shows
3. Bike can be operated 3 ways. As a regular bike, in pedal assist or by throttle
4. The up/down arrows dictate the level of assist. 1=less assist 3=more assist
5. To use thumb throttle the pedal assist mode on LCD display must be on at least on mode 1
6. Use gears 3-7 on gear shifter if riding like a regular bike. Otherwise always keep in **gear 7 for optimum use**
7. When finished turn key to “OFF” position
8. Button on top of battery will inform you of battery power left.